

ダイアセラム

洋の器

水明白  
和の器

中華の器



9-117-1-44724001 ¥1,760  
24cmボール 24.1×9.3-1,920cc



9-117-2-44721001 ¥1,050  
21cmボール 21.3×9-1,400cc



9-117-3-44719001 ¥880  
19cmボール 19.5×8-1,100cc



9-117-4-44716001 ¥580  
16cmボール 16.5×7.1-600cc



9-117-5-44714001 ¥480  
14cmボール 14×6.5-420cc



9-117-6-44711001 ¥420  
11cmボール 11.4×6.3-270cc  
9-117-7-10210001 ¥250  
ソーサー 15.3×2.1



9-117-8-44709001 ¥400  
9cmボール 9.2×5.3-160cc



9-117-9-44819001 ¥1,100  
19cm深ボール 18.6×10.2-1,230cc



9-117-10-44818001 ¥950  
18cm深ボール 18×9.2-1,000cc



9-117-11-44816001 ¥740  
16cm深ボール 16.5×8.7-780cc



9-117-12-44815001 ¥690  
15cm深ボール 14.8×8.5-660cc



9-117-13-44813001 ¥570  
14cm深ボール 13.7×7.8-500cc



9-117-14-44812001 ¥510  
12cm深ボール 12.2×7.3-340cc



9-117-15-44809001 ¥420  
9cm深ボール 9.4×6.2-210cc  
9-117-16-10210001 ¥250  
受皿 15.3×2.1



9-117-17-44901001 ¥520  
フリーカップ70  
9×7-210cc  
9-117-18-10210001 ¥250  
受皿 15.3×2.1



9-117-19-44902001 ¥750  
フリーカップ90  
9.2×9-280cc  
9-117-20-10210001 ¥250  
受皿 15.3×2.1



9-117-21-44903001 ¥910  
フリーカップ120  
9.2×12-430cc



9-117-22-44100001 ¥380  
コーヒー碗  
8.3×6.6-160cc  
9-117-23-10210001 ¥250  
受皿 15.3×2.1  
碗皿 ¥630



9-117-24-44904001 ¥580  
オープンハンドル70  
9×7-210cc  
9-117-25-10210001 ¥250  
受皿 15.3×2.1  
碗皿 ¥830



9-117-26-44905001 ¥860  
オープンハンドル90  
9.2×9-280cc  
9-117-27-10210001 ¥250  
受皿 15.3×2.1  
碗皿 ¥1,110



9-117-28-44906001 ¥1,010  
オープンハンドル120  
9.2×11.8-430cc