






- | | | | | |
|---|---|---|---|--|
|  |  |  |  | |
| 9-8-1-49210001 ¥540 11cm菊型深鉢 11×5.5・320cc | 9-8-2-49220001 ¥540 11cm菊型浅鉢 10.9×3.3 | 9-8-3-49240001 ¥1,000 10cm角鉢 9.8×3.6 | 9-8-4-49230001 ¥1,100 9cm隅切角小鉢 9.4×4.9 | |
|  |  |  |  |  |
| 9-8-5-51250001 ¥630 13cmボール 12.7×5.5・270cc | 9-8-6-51497001 ¥580 12cmボール 11.5×4.8・230cc | 9-8-7-51240001 ¥530 10cmボール 10.5×4.9・200cc | 9-8-8-54030001 ¥600 11cm京茶碗 11.5×5.4・260cc | 9-8-9-51490001 ¥320 11cm茶碗 11×4.6・210cc |
|  |  |  | | |
| 9-8-10-49180001 ¥760 12cm六山鉢 12×5.8・300cc | 9-8-11-49190001 ¥710 11cm六山鉢 11.1×4.8・200cc | 9-8-12-50505001 ¥650 13cm耳付小鉢 12.8×11.3×4.2 | | |
|  |  |  |  |  |
| 9-8-13-90710001 ¥680 ミルクカップ 7.7×6・180cc | 9-8-14-49420001 ¥520 長湯呑 6.3×7.5・160cc | 9-8-15-50481001 ¥550 反湯呑 9.3×5.8・200cc | 9-8-16-51130001 ¥860 マグカップ 7.3×7.3・200cc | 9-8-17-51139001 ¥810 スタックカップ 7.3×7.6・200cc |
|  |  |  | | |
| ¥1,500 9-8-18-49010001 ¥810 ライス碗 (大) 14.8×7.1・400cc | ¥1,450 9-8-20-49020001 ¥790 ライス碗 (中) 13.4×7・300cc | ¥1,350 9-8-22-49030001 ¥700 ライス碗 (小) 12.2×5.9・200cc | | |
| 9-8-19-49070001 ¥690 蓋 (大) 13.1×3.6 | 9-8-21-49080001 ¥660 蓋 (中) 12.2×3.3 | 9-8-23-49090001 ¥650 蓋 (小) 10.9×3.3 | | |
|  |  |  |  | |
| ¥1,500 9-8-24-49040001 ¥810 多用碗 (大) 14.8×6.1・300cc | ¥1,450 9-8-26-49050001 ¥790 多用碗 (中) 13.6×6.1・300cc | ¥1,350 9-8-28-49060001 ¥700 多用碗 (小) 12.2×5.9・250cc | ¥1,350 9-8-30-49500001 ¥700 ココット 13.3×12×8.7・310cc | |
| 9-8-25-49070001 ¥690 蓋 (大) 13.1×3.6 | 9-8-27-49080001 ¥660 蓋 (中) 12.2×3.3 | 9-8-29-49090001 ¥650 蓋 (小) 10.9×3.3 | 9-8-31-49090001 ¥650 蓋 (小) 10.9×3.3 | |
|  |  |  |  | |
| ¥1,030 9-8-32-49100001 ¥600 丸深鉢 10.6×6.7・280cc | ¥970 9-8-34-49110001 ¥540 丸小鉢 10.6×6・220cc | ¥1,050 9-8-36-49140001 ¥620 茶碗蒸 7.4×6.6・170cc | ¥1,200 9-8-39-50100001 ¥770 カップ 7.8×6.5・190cc | |
| 9-8-33-49171001 ¥430 かぶせ蓋 (大) 11×2 | 9-8-35-49171001 ¥430 かぶせ蓋 (大) 11×2 | 9-8-37-49172001 ¥430 かぶせ蓋 (小) 8.4×1.7 | 9-8-40-49172001 ¥430 かぶせ蓋 (小) 8.4×1.7 | |
| | | 9-8-38-50604001 ¥430 受皿 10×2 | | |