



21700130 2¾"深皿 ¥450 D6.9×H2 RF	21700131 3"深皿 ¥480 D7.5×H1.8 RF	21700132 3¾"深皿 ¥600 D9.8×H2.6 RF	21700134 4"深皿 ¥680 D11.1×H2.8 RF	21700141 5"取皿 ¥700 D12.7×H2.7 RF	21700142 5½"取皿 ¥730 D13.7×H3 RF	21700140 5"小皿 ¥700 D12.4×H1.9 RF	21700137 5½"深口皿 ¥730 D14.1×H2.6 RF
---	--	---	---	---	--	---	---




21700540 4"スープ碗 ¥700 D10.3×H4.8・170cc RF	21700541 4½"スープ碗 ¥780 D11.7×H5.5・240cc RF	21700321 2½"千茶 ¥630 D7.4×H5.3・120cc RF	60100342 エスプレッソ受皿 ¥650 D12×H2.1 RF	21700326 4"反千茶 ¥700 D9.8×H5.7・190cc RF	60100342 エスプレッソ受皿 ¥650 D12×H2.1 RF	21700531 4½"ライスボール ¥830 D11×H4.8・215cc RF	21700296 4½"飯井 ¥1,100 D11.6×H6.2・390cc RF
---	--	---	---	---	---	--	--



21700298 4½"玉井(特白磁) ¥700 D11.5×H4.4・210cc RF	21700301 6"玉井 ¥1,750 D15.5×H6・510cc RF	21700305 7½"玉井 ¥2,200 D19.6×H7.1・1100cc RF	21700312 8"玉井 ¥3,200 D21.2×H7.7・1410cc RF	21700306 7½"八角高台 ¥2,500 D18.7×H4.7 RF (特白磁)
---	---	---	--	---



21700313 8"ラーメン井 ¥1,500 D19.6×H6.4 RF	21700550 8"スープボール ¥2,600 D20.2×H7.5・1320cc RF	21700552 9"スープボール ¥3,600 D22.5×H7.9・1750cc RF	21700555 10"スープボール ¥5,400 D25.3×H8.8・2500cc RF
--	--	--	---



21700070 6½"丸皿 ¥780 D16.5×H1.8 RF	21700071 7½"丸皿 ¥1,050 D18.8×H1.9 RF	21700072 8"丸皿 ¥1,150 D20.7×H2 RF	21700074 9"丸皿 ¥1,500 D23.5×H2.5 RF	21700075 10"丸皿 ¥2,400 D26.1×H2.6 RF	21700076 12"丸皿 ¥4,000 D30.8×H3.6 RF	21700078 14"丸皿 ¥10,000 D35.3×H3.7 RF	21700079 16"丸皿 ¥20,000 D40.1×H4.4 RF
--	--	---	---	--	--	---	---



21700188 7"プラター ¥1,450 L18.5×S13.4×H1.9 RF (特白磁)	21700195 8"プラター ¥1,600 L21×S14.8×H2.3 RF (特白磁)	21700196 9"プラター ¥1,800 L23.5×S16.7×H2.4 RF (特白磁)	21700197 10"プラター ¥2,600 L26.1×S18.9×H2.6 RF (特白磁)	21700198 12"プラター ¥4,000 L30.9×S22.4×H3.2 RF (特白磁)	21700199 14"プラター ¥7,300 L36.1×S26.8×H3.6 RF (特白磁)
--	--	--	---	---	---