




8-967-1 A-11-37
 折りたたみ椅子
 ワイン(レザー) SH35
 ¥22,000
 (49×52×H66×SH35)



8-967-2 A-11-58
 折りたたみ椅子
 グリーン(布) SH43
 ¥24,000
 (55×53×H73×SH43)



8-967-3 A-11-76
 あぐら椅子
 ブラウン(布)
 ¥20,500
 (46.3×47×H30×SH16)



8-967-4 A-11-77
 あぐら椅子
 グレー(レザー)
 ¥19,500
 (46.3×47×H30×SH16)



8-968-1 A-3-46
 大和高椅子
 ベージュ(布)(横張り)
 ¥32,000
 (44×48×H71×SH35) 梱4



8-968-2 A-3-47
 大和高椅子
 レザー・クリーム(横張り)
 ¥32,000
 (44×48×H71×SH35) 梱4



8-968-3 A-3-49
 桃山高椅子
 グリーン(布)
 ¥32,000
 (44.5×49×H71×SH35) 梱4



8-968-4 高椅子 喜楽 白木、布地
 A-2-5 35H ¥33,500
 (44×50×H71×SH35) 梱4
 A-2-6 27H ¥30,000
 (44×50×H58.5×SH27) 梱4



8-967-5 A-11-42
 青山低椅子
 グリーン(布) SH27
 ¥21,000
 (49×50×H59×SH27)



8-967-6 A-11-73
 立山低椅子
 アイボリー(レザー) SH27
 ¥20,000
 (49×50×H59×SH27)



8-967-7 A-11-59
 スツール
 グリーン(布) SH33.5
 ¥10,500
 (46×39×H33.5)



8-967-8 A-11-60
 スツール
 アイボリー(レザー) SH43.5
 ¥11,500
 (47×41×H43.5)



8-968-5 A-2-3
 高椅子 喜楽35N
 サベリ色、布地
 ¥33,500
 (44×50×H71×SH35) 梱4



8-968-6 A-2-48
 新優高椅子
 ベージュ(布)(横張り)
 ¥34,000
 (44.5×48×H71×SH35) 梱4



8-968-7 A-3-48
 6本格子高椅子
 ベージュ(布)
 ¥32,000
 (44.5×49×H71×SH35) 梱4



8-968-8 A-3-44
 新優高椅子
 レザー・グリーン(縦張り)
 ¥34,000
 (44.5×48×H71×SH35) 梱4



8-967-9 A-1-2
 優高椅子
 ベージュ(布) SH35
 ¥32,000
 (45×48×H71×SH35)



8-967-10 A-2-35
 優高椅子
 レザー・クリーム SH35
 ¥32,000
 (45×48×H71×SH35)



8-967-11 A-2-49
 新優高椅子
 レザー・クリーム(横張り) SH35
 ¥34,000
 (44.5×48×H71×SH35)



8-967-12 A-11-36
 折りたたみオットマン
 グリーン(布)
 ¥11,500
 (47×31×H24)



8-968-9 A-2-47
 新優高椅子
 グリーン(布)(縦張り)
 ¥34,500
 (44.5×48×H71×SH35) 梱4



8-968-10 A-4-92
 あすか高椅子
 開花 朱べに花(布)
 ¥37,000
 (43×49×H72×SH35) 梱4



8-968-11 A-2-8
 あすか高椅子
 開花 ビニールレザー茶
 ¥37,000
 (43×49×H72×SH35) 梱4



8-968-12 A-3-55
 鎌倉高椅子
 ベージュ(布)
 ¥38,500
 (44×48×H71×SH35) 梱4