



585 06 001  
27cmプレート  
D-27 H-3.1 ¥1,800



585 06 003  
24cmプレート  
D-24 H-2.8 ¥1,100



585 06 006  
18cmプレート  
D-18 H-2.1 ¥650



585 06 074 31cmワイドプラター  
L-31.2 S-22 H-2.9 ¥3,100



585 06 044 31cmプラター  
L-31 S-16.5 H-2.9 ¥2,800



585 06 085 29cmベーカー  
L-29.5 S-19.2 H-5.5 ¥3,500



585 06 023 24.5cmパスタボウル  
D-24.5 H-4.4 ¥1,600



585 06 018 15cmボウル  
D-15 H-5 ¥600



585 06 051 カプチーノカップ  
L-12.4 S-9.5 H-6.8 C-250cc ¥900



585 06 052 コーヒーカップ  
L-11.9 S-9 H-6.5 C-210cc ¥800

570 06 055 兼用ソーサー  
D-15.3 H-2.1 ¥500

570 06 055 兼用ソーサー  
D-15.3 H-2.1 ¥500

CONTRNO

GREEN グリーン



585 07 001  
27cmプレート  
D-27 H-3.1 ¥1,800



585 07 003  
24cmプレート  
D-24 H-2.8 ¥1,100



585 07 006  
18cmプレート  
D-18 H-2.1 ¥650



585 07 074 31cmワイドプラター  
L-31.2 S-22 H-2.9 ¥3,100



585 07 044 31cmプラター  
L-31 S-16.5 H-2.9 ¥2,800



585 07 085 29cmベーカー  
L-29.5 S-19.2 H-5.5 ¥3,500



585 07 023 24.5cmパスタボウル  
D-24.5 H-4.4 ¥1,600



585 07 018 15cmボウル  
D-15 H-5 ¥600



585 07 051 カプチーノカップ  
L-12.4 S-9.5 H-6.8 C-250cc ¥900



585 07 052 コーヒーカップ  
L-11.9 S-9 H-6.5 C-210cc ¥800

570 07 055 兼用ソーサー  
D-15.3 H-2.1 ¥500

570 07 055 兼用ソーサー  
D-15.3 H-2.1 ¥500