



**580 00 002**  
27.5cmプレート  
D-27.5 H-2.8  
¥1,700



**580 00 003**  
24.5cmプレート  
D-24.8 H-2.4  
¥900



**580 00 005**  
23cmプレート  
D-23.5 H-2.4  
¥800



**580 00 007**  
21.5cmプレート  
D-21.8 H-2.2  
¥700



**580 00 008**  
19.5cmプレート  
D-19.5 H-2  
¥650



**580 00 009**  
17cmプレート  
D-17.5 H-1.9  
¥550



**580 00 011**  
16cmプレート  
D-16 H-1.7  
¥500



**580 00 030**  
26.5cmリムスープボウル  
D-26.8 H-4.7 ¥1,800



**580 00 032**  
23.5cmリムスープボウル  
D-23.8 H-5 ¥1,400



**580 00 020**  
13cmボウル  
D-13.5 H-7.5 ¥1,000



**580 00 021**  
12cmボウル  
D-12 H-6.8 ¥850



**580 00 022**  
11cmボウル  
D-11 H-6.2 ¥750



**580 00 051** カプチーノカップ  
L-12 S-9.5 H-6.8 C-250cc ¥900  
**580 00 055** 兼用ソーサー  
D-15.3 H-2 ¥500



**580 00 052** コーヒーカップ  
L-11.5 S-8.8 H-6.4 C-185cc ¥750  
**580 00 055** 兼用ソーサー  
D-15.3 H-2 ¥500



**580 00 058** エスプレッソカップ  
L-9.8 S-7.4 H-5.2 C-110cc ¥650  
**580 00 059** エスプレッソソーサー  
D-12.6 H-1.7 ¥450