



**149 00 011**  
23cm深皿  
D-23 H-4.5  
¥3,300



**149 00 013**  
18cm深皿  
D-18 H-3.4  
¥2,200



**149 00 014**  
15.5cm深皿  
D-15.5 H-2.9  
¥1,900



**149 00 015**  
13.5cm深皿  
D-13.4 H-2.7  
¥1,600



**149 00 016**  
12cm深皿  
D-12 H-2.4  
¥1,200



**149 00 018**  
10.5cm深皿  
D-10.5 H-2.1  
¥900



**149 00 025**  
15cmボウル  
D-15 H-4.6  
¥2,000



**149 00 026**  
12.5cmボウル  
D-12.5 H-3.8  
¥1,400



**149 00 027**  
9.5cmボウル  
D-9.5 H-2.8  
¥1,000



**149 00 036**  
13cm深ボウル  
D-13.1 H-6.3  
¥1,900



**149 00 037**  
10cm深ボウル  
D-10 H-4.7  
¥1,200



**149 00 039**  
7cm深ボウル  
D-7 H-3.4  
¥700



**195 00 061**  
8.5cm醤油皿  
D-8.6 H-2.2  
¥750



**149 00 099**  
7.5cm醤油皿  
D-7.8 H-2.2  
¥600



**149 00 094**  
6連菜  
L-26.3 S-16.9 H-2.8  
¥3,900



**149 00 096**  
4連菜  
L-32.7 S-9.2 H-2.7  
¥2,900



**149 00 097**  
3連菜  
L-26.5 S-9.2 H-2.6  
¥2,300




**149 00 098**  
深型3連菜  
L-26.1 S-8.9 H-3.5  
¥2,300



**149 00 069**  
2連菜  
L-18.6 S-9.2 H-2.7  
¥1,500




**149 00 092**  
トレイ付3連菜  
L-26.5 S-22.5 H-3  
¥4,100



**149 00 030**  
6菜深皿  
L-28.8 S-19.1 H-2.9  
¥4,400




**149 00 031**  
4連深皿  
D-23.7 H-2.4  
¥3,800



**149 00 032**  
3連深皿  
L-29.1 S-9.7 H-2.9  
¥2,700



**149 00 033**  
2連深皿  
L-19.3 S-9.7 H-2.9  
¥1,600



**149 00 062**  
3連皿  
L-32.8 S-10.9 H-1.7  
¥2,900



**149 00 063**  
2連皿  
L-22.2 S-11.1 H-1.7  
¥1,900



**149 00 083**  
28.5cm長角トレイ  
L-28.8 S-9.5 H-2.8  
¥2,100



**149 00 086**  
19.5cm長角トレイ  
L-19.6 S-9.6 H-2.8  
¥1,800



**149 00 052**  
コーヒーカップ  
L-10.9 S-8.1 H-7.2 C-180cc ¥950  
**149 00 055**  
コーヒーソーサー  
D-12.3 H-1.6 ¥900



**149 00 058**  
エスプレッソカップ  
L-8.7 S-6.5 H-5.7 C-100cc ¥850  
**149 00 059**  
エスプレッソソーサー  
D-11.1 H-1.6 ¥750