



**177 00 045**  
35cm角プラター  
L-35 S-24 H-3.2 **¥5,000**



**177 00 046**  
31cm角プラター  
L-31.3 S-21.7 H-3.1 **¥3,800**



**177 00 047**  
28.5cm角プラター  
L-28.7 S-20 H-2.8 **¥3,300**



**177 00 026**  
15cmマルチボウル  
D-15 H-8.3 **¥1,600**



**177 00 027**  
13.5cmマルチボウル  
D-13.5 H-7.5 **¥1,100**



**177 00 028**  
12cmマルチボウル  
D-12 H-6.9 **¥950**



**177 00 029**  
11cmマルチボウル  
D-11 H-6.3 **¥850**



**177 00 030**  
9cmマルチボウル  
D-9 H-6.2 **¥700**



**177 00 023**  
17cm洋ボウル  
D-17 H-7.1 **¥1,800**



**177 00 025**  
13cm洋ボウル  
D-13 H-5.4 **¥1,100**



**177 00 032**  
15cm多用井  
D-15 H-8.1 **¥1,800**



**177 00 033**  
13cm多用井  
D-13.3 H-7.2 **¥1,500**



**177 00 034**  
11.5cm多用井  
D-11.5 H-6.1 **¥1,100**



**176 00 046**  
16.5cm  
ソフトスクエアボウル  
D-16.7 H-7 **¥2,200**



**176 00 047**  
14.5cm  
ソフトスクエアボウル  
D-14.6 H-6.3 **¥1,600**



**176 00 048**  
12cm  
ソフトスクエアボウル  
D-12.1 H-5.3 **¥1,200**



**176 00 049**  
9.5cm  
ソフトスクエアボウル  
D-9.6 H-4.3 **¥900**



**176 00 044**  
13.5cm  
ソフトスクエア深皿  
D-13.8 H-4.2 **¥1,400**



**176 00 045**  
11.5cm  
ソフトスクエア深皿  
D-11.6 H-3.4 **¥1,000**



**177 00 051**  
カプチーノカップ  
L-11.1 S-8.4 H-7.9 C-250cc **¥950**

**127 00 055**  
兼用ソーサー  
D-15.2 H-2.2 **¥600**



**177 00 052**  
コーヒーカップ  
L-10.1 S-7.5 H-6.7 C-160cc **¥850**

**177 00 054**  
コーヒーソーサー  
D-14.5 H-1.8 **¥750**



**177 00 058**  
エスプレッソカップ  
L-8.6 S-6.3 H-5.9 C-105cc **¥750**

**170 00 059**  
エスプレッソソーサー  
D-12.8 H-1.7 **¥550**