



252 20 002  
27cmディナー皿  
D-27.3 H-2.3  
¥2,600

252 20 003  
25cmディナー皿  
D-25 H-2.1  
¥2,300

252 20 004  
23cmミート皿  
D-23 H-1.9  
¥1,500

252 20 005  
21cmミート皿  
D-21 H-1.8  
¥1,300

252 20 006  
19cmケーキ皿  
D-19 H-1.7  
¥1,100

252 20 007  
17cmパン皿  
D-17 H-1.5  
¥900



252 20 010  
26cmスープボウル  
D-26.1 H-4.3 ¥2,700



252 20 011  
23cmスープボウル  
D-23.2 H-3.4 ¥1,900



252 20 012  
21cmスープボウル  
D-21.3 H-3.2 ¥1,600



252 20 024  
16cmボウル  
D-16 H-5.6 ¥1,800



252 20 025  
13.5cmボウル  
D-13.8 H-4.9 ¥1,300



252 20 026  
12cmボウル  
D-12.3 H-4.2 ¥1,100



252 20 027  
10cmボウル  
D-10.3 H-3.6 ¥850



252 20 013  
18.5cmスープボウル  
D-18.7 H-4.4 ¥1,300



252 20 014  
15.5cmフルーツボウル  
D-15.8 H-3.8 ¥1,100



252 20 016  
12.5cmデザートボウル  
D-12.7 H-3.4 ¥950



252 20 052  
コーヒーカップ  
L-10.3 S-7.7 H-6.7 C-162cc  
¥950



252 20 058  
デミタスカップ  
L-8.6 S-6.6 H-5.6 C-105cc  
¥850



252 20 054  
両手スープカップ  
L-15.3 S-11.1 H-5.5 C-300cc  
¥1,400



252 20 152  
取手付コーヒーカップ  
L-10.3 S-7.7 H-6.7 C-162cc  
¥950

252 20 055  
兼用ソーサー  
D-14.5 H-1.9 ¥650

252 20 059  
デミタスソーサー  
D-12.4 H-1.7 ¥600

252 20 055  
兼用ソーサー  
D-14.5 H-1.9 ¥650