



111 30 021
23cmボウル
D-23.2 H-8.3
¥2,600



111 30 022
21.5cmボウル
D-21.5 H-7.5
¥2,300



111 30 023
20cmボウル
D-20 H-7
¥1,900



111 30 024
17cmボウル
D-17 H-6.3
¥1,400



111 30 025
13.5cmボウル
D-13.7 H-5.5
¥900



111 30 026
12cmボウル
D-12.1 H-4.8
¥850



111 30 027
10cmボウル
D-10.2 H-4.1
¥750



110 30 028
8.5cmボウル
D-8.5 H-3.5
¥700



111 30 015
24cmスープボウル
D-24 H-6 ¥2,100



111 30 016
20cmスープボウル
D-20 H-5.3 ¥1,200



111 30 031
17.5cmマルチボウル
D-17.8 H-9 ¥1,600



111 30 032
15cmマルチボウル
D-15.4 H-7.5 ¥1,400



111 30 033
12cmマルチボウル
D-12.4 H-6.6 ¥950



111 30 034
10cmマルチボウル
D-10.3 H-5.6 ¥900



111 30 028
12.5cm深ボウル
D-12.5 H-7.8 ¥1,100



111 30 029
11cm深ボウル
D-11.4 H-6.9 ¥700



110 30 095
13cm深取り皿
D-13 H-3.1 ¥750



110 30 018
10cmタレ皿
D-10 H-2.7 ¥650



110 30 058
13.5cmカフェオレボウル
D-13.6 H-7 ¥1,300



111 30 052
コーヒーカップ
L-10.5 S-7.8 H-7.3 C-180cc
¥700
111 30 056
コーヒーソーサー
D-14.3 H-2.5 ¥650