






FROSTY WHITE | フロスティーホワイト

						
126 00 002 26cmディナー皿 D-25.4 H-3.2 ¥2,100	126 00 004 23cmミート皿 D-22.8 H-3.1 ¥1,500	126 00 006 19.5cmケーキ皿 D-19.3 H-2.8 ¥950	126 00 007 17.5cmパン皿 D-17.8 H-2.4 ¥900	126 00 008 15cmパン皿 D-15 H-2.3 ¥850	126 00 015 24cmスープボウル D-24 H-6 ¥2,000	126 00 016 20cmスープボウル D-20 H-5.2 ¥1,300
						126 00 071 27cmペーサー L-27 S-17.2 H-5.5 ¥3,500
126 00 044 28.5cmプラター L-28.5 S-22.4 H-4 ¥4,000	126 00 045 26cmプラター L-26 S-19.8 H-3.5 ¥2,900	126 00 046 24cmプラター L-24 S-18.4 H-3.2 ¥2,100				134 00 098 7.5cmソースカップ D-7.6 H-4.4 ¥700
						
126 00 024 17cmボウル D-16.5 H-6.2 ¥1,400	126 00 025 13.5cmボウル D-13.4 H-5.5 ¥850	126 00 027 10cmボウル D-10.2 H-4.1 ¥700	126 00 050 マグカップ L-12.7 S-9.3 H-8 C-320cc ¥1,100	126 00 056 ラテカップ L-14.8 S-12 H-6.7 C-415cc ¥1,400	126 00 057 ラテソーサー D-17.5 H-2.5 ¥850	126 00 052 コーヒーカップ L-11 S-8.4 H-6.2 C-180cc ¥750
						
			126 00 055 コーヒーソーサー D-14 H-2.4 ¥650			