




**139 00 002**  
27cm丸皿  
D-27.1 H-3.1 **¥2,600**



**139 00 003**  
25.5cm丸皿  
D-25.5 H-2.8 **¥2,100**



**139 00 004**  
23.5cm丸皿  
D-23.7 H-2.5 **¥1,300**



**139 00 005**  
21.5cm丸皿  
D-21.5 H-2.2 **¥1,200**



**139 00 006**  
19.5cm丸皿  
D-19.5 H-2 **¥1,100**



**139 00 010**  
27cmスープボウル  
D-27 H-4.3 **¥2,500**



**139 00 011**  
23.5cmスープボウル  
D-23.5 H-3.7 **¥1,600**



**139 00 012**  
22cmスープボウル  
D-22 H-3.5 **¥1,400**



**139 00 061**  
27cmスクエアプレート  
D-27.1 H-1.7 **¥4,400**



**139 00 062**  
25cmスクエアプレート  
D-25.2 H-1.6 **¥3,500**



**139 00 063**  
23cmスクエアプレート  
D-23 H-1.6 **¥3,300**



**139 00 064**  
20cmスクエアプレート  
D-20 H-1.5 **¥2,600**



**139 00 072**  
27cmスワンベーカー  
L-27.2 S-17 H-7.8 **¥3,700**



**139 00 073**  
25cmスワンベーカー  
L-25.1 S-15.6 H-7.1 **¥3,400**



**139 00 075**  
22cmスワンベーカー  
L-22.3 S-14.2 H-6.4 **¥2,700**



**139 00 035**  
14cmスワンボウル  
L-14 S-8.5 H-6.7 **¥1,800**



**139 00 036**  
10cmスワンボウル  
L-10.3 S-5.9 H-4.9 **¥1,200**



**139 00 086**  
11.5cmトールボウル  
D-11.7 H-8.5 **¥1,300**



**139 00 087**  
10cmトールボウル  
D-10 H-7 **¥950**



**139 00 088**  
8cmトールボウル  
D-8 H-5.6 **¥750**



**139 00 052**  
コーヒーカップ  
L-10.2 S-8.2 H-6.1 C-170cc **¥850**

**139 00 055**  
兼用ソーサー  
D-15.2 H-2.2 **¥600**