



171 00 090
36cmオーバル皿
L-36.2 S-16.3 H-3 **¥6,000**



171 00 092
31cmオーバル皿
L-31.3 S-14 H-3 **¥3,200**



171 00 093
26cmオーバル皿
L-26.4 S-11.5 H-2.2 **¥1,800**



171 00 081
35.5cmオーバル長皿
L-35.8 S-12 H-2.5 **¥4,100**



171 00 082
33cmオーバル長皿
L-33.3 S-10.9 H-2.3 **¥2,500**



171 00 083
30.5cmオーバル長皿
L-30.7 S-10.1 H-2.1 **¥2,300**



171 00 084
27.5cmオーバル長皿
L-27.7 S-8.9 H-1.8 **¥2,000**



171 00 095
24.5cmオーバル長皿
L-24.6 S-7.9 H-1.6 **¥1,400**



172 00 031
24cmデュードロップ浅ボウル
L-24 S-19.3 H-4.6 **¥2,900**



172 00 033
20.5cmデュードロップ浅ボウル
L-20.5 S-16.5 H-4.4 **¥2,500**



172 00 035
17.5cmデュードロップ浅ボウル
L-17.8 S-14.2 H-4 **¥1,600**



172 00 036
14.5cmデュードロップ浅ボウル
L-14.7 S-11.5 H-3.6 **¥1,300**



172 00 037
12cmデュードロップ浅ボウル
L-12 S-9.3 H-3.3 **¥1,000**



171 00 013
19.5cmスープボウル
D-19.5 H-5.7 **¥1,100**



171 00 014
17.5cmスープボウル
D-17.6 H-5.2 **¥950**



171 00 015
15.5cmフルーツボウル
D-15.5 H-4.6 **¥850**



171 00 016
13cmフルーツボウル
D-13.4 H-4.1 **¥700**



172 00 013
19cmデザートボウル
D-19.4 H-4.9 **¥1,100**



172 00 014
16cmデザートボウル
D-16 H-4.2 **¥950**



172 00 016
13cmデザートボウル
D-13.3 H-3.4 **¥850**



171 00 054
両手スープカップ
L-15.6 S-10.4 H-5.6 C-270cc
¥1,400
170 00 055
兼用ソーサー
D-15.2 H-2.2 **¥600**



171 00 056
片手スープカップ
L-12.9 S-10.4 H-5.6 C-270cc
¥1,300
170 00 055
兼用ソーサー
D-15.2 H-2.2 **¥600**



171 00 051
カプチーノカップ
L-11.5 S-9 H-6.7 C-205cc
¥950
170 00 055
兼用ソーサー
D-15.2 H-2.2 **¥600**



171 00 052
コーヒーカップ
L-10.8 S-8.3 H-6.2 C-160cc
¥850
170 00 055
兼用ソーサー
D-15.2 H-2.2 **¥600**



171 00 058
エスプレッソカップ
L-9 S-7.2 H-5.3 C-100cc
¥750
170 00 059
エスプレッソソーサー
D-12.8 H-1.7 **¥550**



197 00 658
エスプレッソカップ小
L-9 S-6.7 H-4.6 C-65cc
¥700
170 00 059
エスプレッソソーサー
D-12.8 H-1.7 **¥550**