




127 00 002  
27cmプレート  
D-27.3 H-2.4  
¥2,400



127 00 003  
25cmプレート  
D-25 H-2.3  
¥2,200




127 00 004  
23cmプレート  
D-23 H-2.2  
¥1,500



127 00 005  
21cmプレート  
D-21.4 H-2  
¥1,300



127 00 006  
19.5cmプレート  
D-19.5 H-1.9  
¥1,200



127 00 007  
17.5cmプレート  
D-17.5 H-1.8  
¥950



127 00 008  
15.5cmプレート  
D-15.7 H-1.8  
¥750



127 00 071  
27cm盛皿  
D-27.1 H-1.8 ¥3,300



127 00 010  
24.5cmリムスープボウル  
D-24.7 H-4 ¥2,200



127 00 011  
23cmリムスープボウル  
D-23 H-3.7 ¥1,500



127 00 075  
29cmリーフベーカー  
L-29 S-21.3 H-4.9 ¥3,800



127 00 034  
18cmリムボウル  
D-18.1 H-5.7 ¥1,900