



123 00 091
35.5cmプラター
L-35.8 S-23.5 H-4.5 **¥4,800**



123 00 093
33.5cmプラター
L-33.5 S-22.2 H-4.2 **¥4,200**



123 00 094
31.5cmプラター
L-31.5 S-20.9 H-3.9 **¥3,700**



123 00 023
18.5cmボウル
D-18.6 H-6.6 **¥2,100**



123 00 024
16cmボウル
D-16.1 H-5.7 **¥1,600**



123 00 025
13.5cmボウル
D-13.6 H-4.7 **¥1,100**



123 00 027
11cmボウル
D-11.1 H-3.8 **¥950**



123 00 029
7cmミニボウル
D-7 H-2.9 **¥650**



123 00 020
22cm反ボウル
L-22.1 S-13.6 H-7.8 **¥2,900**



123 00 021
17.5cm反ボウル
L-17.7 S-11 H-6.6 **¥2,200**



123 00 022
12cm反ボウル
L-12.4 S-7.7 H-4.5 **¥1,200**



123 00 064
多用カップ
D-9.4 H-7 C-200cc **¥750**



143 00 092
7.5cmトールボウル
D-7.5 H-5.4 **¥750**



123 00 065
22cm浅オープンパン
L-22.3 S-19.2 H-4.4 **¥2,200**



123 00 066
19.5cm浅オープンパン
L-19.5 S-16.6 H-3.8 **¥1,900**



123 00 051
カプチーノカップ
L-12.2 S-10.6 H-8.1 C-260cc
¥1,000

170 00 055
兼用ソーサー
D-15.2 H-2.2 **¥600**



123 00 052
コーヒーカップ
L-11.2 S-9.4 H-7.1 C-200cc
¥900

170 00 055
兼用ソーサー
D-15.2 H-2.2 **¥600**



123 00 058
エスプレッソカップ
L-9.2 S-7.4 H-5.4 C-100cc
¥850

170 00 059
エスプレッソソーサー
D-12.8 H-1.7 **¥550**



123 00 063
クリーマー
L-6.4 S-4.5 H-4 C-26cc
¥850