



141 00 075
17cmティア小鉢
L-17.2 S-10.6 H-5.4 **¥1,600**



141 00 076
15cmティア小鉢
L-15.4 S-9.4 H-4.9 **¥1,400**



141 00 077
13cmティア小鉢
L-13.1 S-8.1 H-4.3 **¥1,100**



141 00 038
11cmティア小鉢
L-11.1 S-7 H-3.7 **¥950**



141 00 037
15.5cmティア片口小鉢
L-15.5 S-10 H-5.2 **¥1,600**



141 00 078
13.5cmティア片口小鉢
L-13.6 S-8.5 H-4.6 **¥1,400**



141 00 079
11.5cmティア片口小鉢
L-11.6 S-7.3 H-4 **¥1,100**



141 00 039
10cmティア片口小鉢
L-10.1 S-6.3 H-3.5 **¥950**



141 00 026
25.5cm深皿
D-25.6 H-6.6 **¥4,400**



141 00 027
22cm深皿
D-22.3 H-5.8 **¥3,300**



141 00 028
20cm深皿
D-20.1 H-5 **¥2,600**



141 00 071
17.5cmスクエアボウル
D-17.6 H-6.9 **¥2,300**



141 00 072
15.5cmスクエアボウル
D-15.5 H-6 **¥1,900**



141 00 073
14cmスクエアボウル
D-14 H-5.5 **¥1,500**



141 00 011
23cm浅ボウル
D-23.2 H-6.2 **¥2,600**



141 00 014
17.5cm浅ボウル
D-17.8 H-4.2 **¥1,200**



141 00 015
13.5cm浅ボウル
D-13.7 H-3.8 **¥850**



142 00 083
からし入れ
D-6.2 H-6.7 **¥900**



199 00 088
ようじ立て
D-3.7 W-4.2 H-5.1 **¥700**



199 00 066
ソース醤油入れ
L-7.6 S-5 H-11.5 C-115cc
¥1,900



199 00 000
カスター3点セット
¥5,300
(199 00 088・142 00 083・199 00 066・142 00 049)



141 00 052
コーヒーカップ
L-10.8 S-8.1 H-6.9 C-185cc
¥850



141 00 058
エスプレッソカップ
L-9.1 S-6.8 H-6 C-100cc
¥750



141 00 068
スティックシュガー&
ナプキンスタンド大
L-10.3 S-8.2 H-8.9 **¥1,600**



141 00 069
スティックシュガー&
ナプキンスタンド小
L-8.7 S-6.5 H-8.2 **¥1,500**

170 00 055
兼用ソーサー
D-15.2 H-2.2 **¥600**

170 00 059
エスプレッソソーサー
D-12.8 H-1.7 **¥550**