




194 00 090
34.5cm角プラター
L-34.4 S-23.1 H-2.2 **¥5,600**



194 00 091
32cm角プラター
L-32 S-21.4 H-2 **¥4,600**



194 00 092
29.5cm角プラター
L-29.5 S-19.7 H-1.9 **¥4,100**



194 00 161
27.5cm角皿
D-27.5 H-3.4
¥4,400

194 00 162
26cm角皿
D-26.5 H-3.3
¥4,200

194 00 163
23cm角皿
D-23.1 H-3.1
¥3,300


194 00 164
20cm角皿
D-20.2 H-3
¥2,600

194 00 165
18cm角皿
D-18 H-2.8
¥2,100


194 00 166
15.5cm角皿
D-15.5 H-2.6
¥1,800



194 00 045
33.5cmリムプラター
L-33.7 S-22.5 H-3.3 **¥5,300**



194 00 046
30cmリムプラター
L-30.1 S-20.2 H-3.2 **¥4,200**



194 00 047
28cmリムプラター
L-28 S-18.5 H-2.9 **¥3,800**



194 00 026
13cmスクエアポウル
D-13 H-3.5 **¥1,500**



194 00 018
10.5cmスクエア深皿
D-10.6 H-2.6 **¥1,100**



194 00 019
9cmスクエア深皿
D-9 H-2.4 **¥950**



194 00 020
7.5cmスクエア深皿
D-8 H-2 **¥850**



194 00 075
13.5cm長角深皿
L-13.7 S-9 H-2.7
¥1,300



194 00 076
12cm長角深皿
L-12.2 S-8.4 H-2.5
¥1,100



194 00 077
10cm長角深皿
L-10.1 S-7 H-2.1
¥950



194 00 052
コーヒーカップ
L-10.7 S-8 H-6 C-170cc **¥950**
139 00 055
兼用ソーサー
D-15.2 H-2.2 **¥600**