



164 00 047
34cm細長プレート
L-34.2 S-12.9 H-3.7 ￥4,100



164 00 048
31cm細長プレート
L-31.4 S-11.9 H-3.1 ￥3,200



164 00 049
28cm細長プレート
L-28 S-11.5 H-2.8 ￥2,600



164 00 061
27cmプレート
L-27 S-25.8 H-3.5
￥4,200



164 00 062
24.5cmプレート
L-24.6 S-23 H-3.2
￥3,700



164 00 063
21.5cmプレート
L-21.7 S-20.4 H-2.8
￥2,700



164 00 064
19.5cmプレート
L-19.7 S-18.6 H-2.5
￥2,500



164 00 080
33cm盛皿
L-33 S-21 H-4.7
￥6,100



164 00 072
30cmリップルワイドプレート
L-30 S-26.9 H-2.6 ￥4,800



164 00 073
26.5cmリップルワイドプレート
L-26.5 S-24 H-2.4 ￥4,100



164 00 074
24cmリップルワイドプレート
L-24 S-22 H-2.2 ￥3,700



164 00 071
30cmリップルプレート
L-30 S-26.6 H-2.2 ￥4,500



156 00 031
17.5cmスクエアーデルタ深ボウル
D-17.5 H-5.8 ￥2,400



156 00 032
15cmスクエアーデルタ深ボウル
D-15 H-4.7 ￥1,900



156 00 033
12cmスクエアーデルタ深ボウル
D-12.2 H-4 ￥1,400



156 00 013
18cmスクエアーデルタ浅ボウル
D-18.1 H-4.3 ￥2,200



156 00 015
14cmスクエアーデルタ浅ボウル
D-14.2 H-3.7 ￥1,600



156 00 016
10.5cmスクエアーデルタ浅ボウル
D-10.8 H-2.8 ￥1,000



157 00 032
15cmデルタ深ボウル
L-15 S-14.4 H-4.9
￥2,000



157 00 033
12.5cmデルタ深ボウル
L-12.5 S-12.2 H-4.1
￥1,400



156 00 051
カプチーノカップ
L-11.9 S-9.4 H-6.1 C-220cc
￥950

170 00 055
兼用ソーサー
D-15.2 H-2.2 ￥600



156 00 052
コーヒーカップ
L-11.4 S-8.7 H-5.8 C-180cc
￥850

170 00 055
兼用ソーサー
D-15.2 H-2.2 ￥600



156 00 058
エスプレッソカップ
L-9.8 S-7.3 H-4.8 C-100cc
￥750

170 00 059
エスプレッソソーサー
D-12.8 H-1.7 ￥550



156 00 086
26.5cmルナディッシュ
L-26.8 S-13.4 H-3.1 ￥2,200



156 00 087
21cmルナディッシュ
L-21.4 S-10.5 H-2.7 ￥1,800



156 00 088
16cmルナディッシュ
L-16 S-7.8 H-2.1 ￥1,200