



156 20 061
26.5cmスクエアプレート
D-26.5 H-3.1 **¥3,500**



156 20 063
23.5cmスクエアプレート
D-23.6 H-2.8 **¥2,900**



156 20 064
20cmスクエアプレート
D-20.1 H-2.6 **¥2,300**



156 20 065
17.5cmスクエアプレート
D-17.5 H-2.3 **¥1,900**



156 20 066
14.5cmスクエアプレート
D-14.8 H-1.9 **¥1,500**



156 20 045
35cm角プラター
L-34 S-23 H-3.2 **¥4,800**



156 20 047
31.5cm角プラター
L-31.8 S-21.8 H-3 **¥3,700**



156 20 049
28cm角プラター
L-28.4 S-19.2 H-3 **¥3,100**



156 20 031
17.5cmスクエア深ボウル
D-17.5 H-5.8 **¥2,300**



156 20 032
15cmスクエア深ボウル
D-15 H-4.7 **¥1,800**



156 20 033
12cmスクエア深ボウル
D-12.2 H-4 **¥1,300**



156 20 013
18cmスクエア浅ボウル
D-18.1 H-4.3 **¥2,100**



156 20 015
14cmスクエア浅ボウル
D-14.2 H-3.7 **¥1,500**



156 20 016
10.5cmスクエア浅ボウル
D-10.8 H-2.8 **¥950**



157 20 035
14.5cmマルチボウル
D-14.7 H-8.1 **¥1,500**



157 20 037
12.5cmマルチボウル
D-12.7 H-7 **¥1,300**



157 20 039
11cmマルチボウル
D-11.2 H-6.1 **¥950**



156 20 080
31.5cmクロワッサン
L-31.5 S-14 H-3.3 **¥3,300**



156 20 082
23.5cmクロワッサン
L-23.5 S-10.4 H-3.1 **¥2,100**



156 20 083
19.5cmクロワッサン
L-19.6 S-8.7 H-2.4 **¥1,500**



156 20 051
カプチーノカップ
L-11.9 S-9.4 H-6.1 C-220cc **¥950**
131 20 055
兼用ソーサー
D-15 H-2.1 **¥600**



156 20 052
コーヒーカップ
L-11.4 S-8.7 H-5.8 C-180cc **¥850**
131 20 055
兼用ソーサー
D-15 H-2.1 **¥600**



156 20 058
エスプレッソカップ
L-9.8 S-7.3 H-4.8 C-100cc **¥750**
121 20 059
エスプレッソソーサー
D-12.7 H-1.7 **¥550**



157 20 063
クリーマー小
L-4.1 S-3.7 H-4.6 C-25cc **¥850**