




132 20 001
31.5cm大皿
D-31.5 H-3.4
¥3,700



132 20 002
27.5cmディナー皿
D-27.5 H-3.2
¥2,100




132 20 004
23cmミート皿
D-23 H-3
¥1,200



132 20 006
19.5cmケーキ皿
D-19.5 H-2.5
¥1,000



132 20 008
15.5cmパン皿
D-15.5 H-2.2
¥700



132 20 046
31cm角プラター
L-31.3 S-21.4 H-2.9 ¥3,700



132 20 047
28.5cm角プラター
L-28.9 S-19.7 H-2.7 ¥3,300



132 20 048
26cm角プラター
L-26.2 S-18 H-2.7 ¥3,000



132 20 075
14.5cm角小皿 CN
L-14.3 S-9.3 H-1.5 ¥1,200



121 20 012
22.5cmカレースパゲティボウル
D-22.7 H-3.5
¥1,300



122 20 023
19cmボウル
D-19 H-6.7
¥1,800



122 20 024
16cmボウル
D-16 H-6
¥1,400



122 20 025
12.5cmボウル
D-12.8 H-5.4
¥950



122 20 027
9.5cmボウル
D-9.6 H-4
¥750



132 20 014
16cmフルーツボウル
D-16 H-4.2 ¥900



132 20 016
13cmデザートボウル
D-13.3 H-3.4 ¥750



193 20 054
22cm浅オープンパン
L-22.1 S-19 H-4.3 ¥2,100



132 20 074
19cm浅オープンパン
L-19.4 S-16.5 H-3.9 ¥1,800



132 20 090
スフレカップ
D-8.4 H-5.3
¥600



132 20 050
マグカップ
L-11 S-8.5 H-7.8 C-270cc
¥1,000



132 20 051
カプチーノカップ
L-11.3 S-9 H-6.5 C-200cc
¥900



132 20 152
Nコーヒーカップ
L-10.7 S-8.4 H-6.1 C-170cc
¥750



132 20 058
エスプレッソカップ
L-9.1 S-7.2 H-5.2 C-100cc
¥750



132 20 052
コーヒーカップ
L-10.4 S-8 H-7.5 C-200cc
¥850



132 20 063
クリーマー
L-4.6 S-4.1 H-3.5 C-24cc
¥750

131 20 055
兼用ソーサー
D-15 H-2.1 ¥600

131 20 055
兼用ソーサー
D-15 H-2.1 ¥600

121 20 059
エスプレッソソーサー
D-12.7 H-1.7 ¥550

132 20 056
コーヒーソーサー
D-15 H-2 ¥600